SUPERÎOR SHIFT TV-DTV **"** HDMI TELEFUNKEN SMART TUBE MENU NET.TV OMENU Replacement remote control for Telefunken® TVs No programming necessary PRONTO ALL'USO BACK EXIT Telecomando di ricambio: sostituisce il vostro telecomando Telefunken®. Non richiede programmazione. 0 MUTE PRÊTE À L'EMPLOI Télécommande de remplacement pour Telefunken®. \$ 1.0 2_{ABC} 3_{DEF} **FUNCIONA DE INMEDIATO** Nando de recambio para los TV Telefunken®. No requiere programación. **4**_{GHI} 5_{JKL} 6_{MNO} 9wxrz **8**_{TUV} 0_ 0 Ö SUPERÎOR

TELEFUNKEN® SMART TV REPLACEMENT

CODE SUPTRB016

BARCODE 8054242080797

TYPE Remote Controls > Consumer

ITEM Telefunken® Smart TV Replacement
DESCRIPTION Infrared universal remote control

compatible with all the Telefunken® TVs

produced after year 2000.

Ready to use: no programming necessary. All of the standard and the smart functions of your original remote are included.

Help Desk service by e-mail within 24-48

hours since your enquiry

SETUP Place batteries and enjoy your Telefunken® TV

BATTERIES 2x 1.5 V - AAA/LR03 (not included)

PACKAGE 40 pcs. box divided into 4 inner boxes (10

pcs./inner box)

DIMENSIONS (40.0 x 35.0 x 32.5) cm

WEIGHT 7.0 kg

BLISTER Remote control, instructions, quarantee

CONTENT



